



ECHO LITE E11 Plus True Wireless Earbuds

User Manual | VWS-141

Introduction

Experience next-level audio with the ECHO LITE E11 Plus, equipped with the latest Bluetooth 6.0 technology for a faster, more stable connection. Enjoy up to 30 hours of total playtime with the compact charging case—perfect for all-day listening. Featuring powerful 13mm dynamic drivers, the E11 Plus delivers crystal-clear, high-definition sound. Customize your audio with app-based EQ controls and create a sound profile that's uniquely yours.

Specifications

Model: E11 Plus

Bluetooth Version: Bluetooth 6.0

Material: ABS

Earbuds' Battery Capacity: 30mAh/0.111Wh

Earbuds' Input Power: 5V~30mA


Charging Case's Battery Capacity: 250mAh/0.925Wh

Charging Case's Input Power: 5V~250mA

Charging Case's Interface: USB-C

Product Overview

- ① MFB
- ② Charging Contact Point
- ③ Acoustic Port
- ④ Function Button
- ⑤ USB-C Charging Port
- ⑥ Indicator Light



Instructions for Use

Power On

Take the earbuds out of the charging case, and the earbuds will automatically power on.

Bluetooth Connecting

Enable the Bluetooth of your mobile phone or other devices, click "Vention E11 Plus" in "Search for Bluetooth Devices", and click "Pairing" when the device is searched.

What's in the Box



Charging Case x 1



Earbuds x 1



Earbuds Tips (L/M/S) x 3



USB-C Charging Cable x 1



User Manual x 1



Lanyard x 1

For more interesting information and events, please follow us on social media platforms:



Facebook



LinkedIn



Instagram

For warranty service or support, please contact Vention team:
Website: www.ventiontech.com Email: vention@ventiontech.com



Bluetooth devices

Download App to Pair the Earbuds

Power Off

Put the earbuds into the charging case to power them off.

Phone Calls

Answer	Double-tap the MFB (L/R)
Hang-Up	Double-tap the MFB (L/R)
Reject	Long Press the MFB (L/R) for 2s

Music Play

Pause/Play	Double-tap the MFB (L/R)
Skip Back	Triple-tap the MFB (L)
Skip Forward	Triple-tap the MFB (R)

Note: The functions listed above are default operations and can be customized in the APP.

Factory Reset

When not connected, tap both earbuds 6 times simultaneously to clear Bluetooth pairing information and restore factory default settings.

Voice Assistant

In the Standby State, long-press the MFB (L/R) for 3s to turn the Voice Assistant on or off.

Charging Indicator Light

- Charging the Case
 - Charging: Orange light flashes
 - Fully Charged: Orange light stays solid

- Battery Status Check (When Not Charging)

- Low Battery: Green light flashes
- Sufficient Battery: Green light stays solid

Note: Short-press the button again to turn off the status light.

APP Usage Guide

- Set custom touch gestures (e.g., play/pause, volume control).
 - Personalize audio profiles by the EQ settings (e.g., bass boost, vocal clarity).
- Note:** For best performance, enable "Allow Auto-Start" and "Allow Background Activity" in your phone's app settings.

Safety Warning

Please read all instructions and warning before using this product. Non-standard use will damage the product or personal safety.

- The battery is included in the product. Please do not expose it to the sunlight, fire or other over-heating environment; Do not store it in high temperature, strong light or magnetic field environment; Do not place it in other harsh environments such as fire source. If water enters, please dry it naturally before use.
- Improper use may easily cause damage to the product or endanger personal and property safety.
- Consumer shall be liable for any personal and property damage resulted from their improper use against the user manual or ignoring the warning, to which our company will not bear any legal liability.
- Non-professional personnel are strictly prohibited from disassembling this product.
- Do not use electrical appliances or loads that exceed the output current of this product.

DOWNLOAD APP TO PAIR THE HEADPHONES

